



Using 2 or 4 mil (preferred) plastic create a tub or catch basin in the bottom to catch waste water. Fasten the plastic to the frame and to each side with duct tape. Double tape all seams.